

**D200 Advanced Workshop
Shooting Menu Set Up**

Pre-Shooting Camera Set Up

<i>Set Up</i>	<i>Manual #</i>	<i>Control</i>	<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
*Exposure Mode	62 to 64	Exposure Mode Button	Manual	Manual	Manual	Aperture Priority
*Shooting Mode	26	Mode Dial	Single	Single	Single	Continuous Low
*Metering Choice	61	Meter Dial	Center Weighted or Spot	Center Weighted or Spot	Center Weighted or Spot	Matrix
*AF Mode	51	Focus Mode Selector	AF-S	AF-S	Manual	AF-C
*AF Area Mode	54	AF-Area Selector	Single	Single	Single	Dynamic

* Must be manually set.

D200 Shooting Menu Set Up

<i>Option</i>	<i>Manual #</i>	<i>Bank A</i>	<i>Bank B</i>	<i>Bank C</i>	<i>Bank C</i>
Name Your Banks		<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
File Naming	129	LAN	NAT	MAC	CAU
Optimize Image	45 to 48	Custom	Custom	Custom	Normal
• Sharpening	46	+2 High	+2 High	+2 High	N/A
• Tone Compensation	47	More Contrast	More Contrast	Normal	N/A
• Color Mode	47	Mode III	Mode III	Mode I	N/A
• Saturation	48	Normal	Normal	Normal	N/A
• Hue Adjustment	48	O	O	O	N/A

D200 Advanced Workshop
Shooting Menu Set Up

<i>Option</i>	<i>Manual #</i>		<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
Color Space	50, 129		sRGB	sRGB	sRGB	sRGB
Image Quality	28, 129		NEW (RAW)	NEW (RAW)	NEW (RAW)	JPEG Fine
Image Size	30, 130		N/A	N/A	N/A	Large
JPEG Compression	31, 130		Optimal Quality	Optimal Quality	Optimal Quality	Optimal Quality
RAW Compression	31, 130		Comp. NEF (RAW)	Comp. NEF (RAW)	Comp. NEF (RAW)	N/A
White Balance	35, 130		Cloudy -2	Cloudy -2	PRE	Cloudy -2
Long Exp. NR	131		Off	Off	Off	Off
High ISO NR	131, 152		Normal	Normal	Normal	Normal
ISO Sensitivity	33, 132		200	200	200	200
Image Overlay	84, 132		N/A	N/A	N/A	N/A
Multiple Exposure	86, 132		OFF	OFF	OFF	OFF
• Number of Shots	86					
• Auto Gain	86					

D200 Advanced Workshop
Shooting Menu Set Up

<i>Option</i>	<i>Manual #</i>	<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
Interval Timer Shooting	89 to 92, 132	OFF	OFF	OFF	OFF
• Start Time	89 to 92				
• Now or Start Time?	89 to 92				
• Interval	89 to 92				
• No. of Intervals	89 to 92				
• Number of Shots	89 to 92				
• Start	89 to 92				
Non CPU Lens Data:	93 to 95, 132				
• Focal Length	93	50mm	50mm	50mm	50mm
• Maximum Aperture	95	f/1.4	f/1.4	f/1.4	f/1.4

Notes: _____

***D200 Advanced Workshop
Shooting Menu Set Up
D200 Custom Setting Menu***

<i>Option</i>		<i>Manual #</i>	<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
	<i>Name Your Banks</i>					
	<i>Autofocus</i>	148 to 152				
a1	AF-C Mode Priority	148		FPS Rate + AF	FPS Rate + AF	FPS Rate + AF
a2	AF-S Mode Priority	148		Focus	Focus	Focus
a3	Focus Area Frame	148		Normal	Normal	Normal
a4	Group Dynamic AF	149 to 150		Pattern 1 Center Area	Pattern 1 Center Area	Pattern 1 Center Area
a5	Lock-On	150		Normal	Normal	Normal
a6	AF Activation	151		AF-ON Only	AF-ON Only	AF-ON Only
a7	AF Area Illumination	151		Off	Off	Off
a8	Focus Area	151		Wrap	Wrap	Wrap
a9	AF Assist Light	152		Off	Off	Off
a10	AF-On for MB-200	152		AF-ON	AF-ON	AF-ON
			<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
	<i>Metering and Exposure</i>	152 to 156				
b1	<i>ISO Auto</i>	152 to 153		Off	Off	Off

D200 Advanced Workshop
Shooting Menu Set Up

	• Maximum Sensitivity			N/A	N/A	N/A	N/A
	• Minimum Shutter Speed			N/A	N/A	N/A	N/A
b2	ISO Step	154		1/3	1/3	1/3	1/2
b3	EV Step	154		1/3	1/3	1/3	1/2
b4	Exposure Compensation Fine Tuning	154		1/3	1/3	1/3	1/2
b5	Easy Exposure Compensation	155		On (Auto Reset)	On (Auto Reset)	On (Auto Reset)	Off
b6	Center Weighted Area	155		6mm	6mm	6mm	8mm
b7	<i>Fine Tune Exposure</i>	156		No	No	No	No
	• Matrix Metering						
	• Center Weighted						
	• Spot Metering						
				<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
	<i>Timers / AE & AF Lock</i>	156 to 157					
c1	AE Lock	156		OFF	OFF	OFF	OFF
c2	AE-L / AF-L	156 to 157		AE Lock Hold / Reset	AE Lock Hold / Reset	AE Lock Hold	AE/AF Lock
c3	Auto Meter Off	157		16 seconds	16 seconds	16 seconds	16 seconds
c4	Self Timer Delay	157		2 seconds	2 seconds	2 seconds	10 seconds

D200 Advanced Workshop
Shooting Menu Set Up

c5	Monitor Off Delay	157		5 Minute	5 Minute	5 Minute	5 Minute
				<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
	Shooting & Display		158 to 160				
d1	Beep	158		OFF	OFF	OFF	OFF
d2	Grid Display	158		OFF	OFF	OFF	OFF
d3	Viewfinder Warning	158		OFF	OFF	OFF	OFF
d4	CL Shooting Speed	158		4 fps	4 fps	N/A	N/A
d5	Exposure Delay Mode	158		On	OFF	On	OFF
d6	File Number Sequence	159		On	On	On	On
d7	LCD Illumination	159		OFF	OFF	OFF	OFF
d8	MB-200 Battery Type	160		N/A	N/A	N/A	N/A
				<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
	Bracketing & Flash		160 to 167				
e1	Flash Sync Speed	160		1/250 (Auto FP)	1/250 (Auto FP)	1/250 (Auto FP)	1/250 (Auto FP)
e2	Flash Shutter Speed	161		1/60 sec	1/60 sec	1/60 sec	1/60 sec
e3	Built-in Flash Mode	161 to 162		TTL	Commander	Commander	TTL
	• TTL	161					

D200 Advanced Workshop
Shooting Menu Set Up

	• Manual	161					
	• Repeating Flash	162					
	• Output	162					
	• Times	162					
	• Interval	162					
	• Commander Only Built-in	163 to 165			--	--	
	• Commander Only – Group A	163 to 165			0.0	-1.7	
	• Commander Only – Group B	163 to 165			0.0	-1.7	
	• Commander Only – Channel	163 to 165			3	3	
e4	Modeling Flash	166		On	On	On	On
e5	Auto Bracketing Set	166		AE	AE	AE	AE
e6	Manual Mode Bracketing	167		N/A	N/A	N/A	N/A
e7	Auto Bracketing Order	167		MTR> Under>Over	MTR> Under>Over	MTR> Under>Over	MTR> Under>Over
e8	Auto Bracketing Selection	167		Manual Value	Manual Value	Manual Value	Manual Value

D200 Advanced Workshop
Shooting Menu Set Up

				<i>Landscape</i>	<i>Nature</i>	<i>Macro</i>	<i>Casual</i>
	<i>Controls</i>		168 to 172				
f1	Center Button Multi-Selector	168		Playback Mode	Playback Mode	Playback Mode	Playback Mode
	• Shooting						
	• Playback			Zoom On/Off	Zoom On/Off	Zoom On/Off	Zoom On/Off
	• Zoom Ratio			Medium	Medium	Medium	Medium
f2	Multi-Selector	169		Do Nothing	Do Nothing	Do Nothing	Do Nothing
f3	Photo Information / Playback	169		OFF	OFF	OFF	OFF
f4	FUNC Button	170		Spot Metering	Spot Metering	Spot Metering	Spot Metering
f5	Command Dials:	170 to 171		N/A	N/A	N/A	N/A
	• Rotate						
	• Reverse Main / Sub						
	• Aperture						
	• Menus & Playback						
f6	Button & Dials	172		Default	Default	Default	Default
f7	No Memory Card	172		Release Locked	Release Locked	Release Locked	Release Locked